

F9G. 2




FIG. 3







FIG. 4A








F9G. 6A


0	Plunc	Jer/	Sul	Plunger/ Support leg
(cm)		Settings	ings	
0	Adjust to 10th notch	to 1	oth	notch
05	adjust to 9th	to	9th	notch
.5-1	adjust to 8th notch	to	8th	notch
1-1.5	adjust to 7th	to	7th	notch
1.5-2	adjust to 6th	to (6th	notch
2-2.5	adjust to 5th	to	5th	notch
2.5-3	adjust to 4th	to	4th	notch
3-3.5	adjust to 3th	to	3th	notch
3.5-4.0	adjust to 2th notch	to	2th	notch
4.0-4.5	adjust to 1st notch	to	1st	notch














F9G. 12







F9G. 18